



Series 475 Mark III Digital Manometer

BATTERY INSTALLATION

Remove the two screws holding the bottom endcap and remove it. Connect the battery to the enclosed battery clip, observing the correct polarity.

When replacing the cover be sure the rubber sealing gasket is properly seated in the gasket channel of the endcap. Note the endcap will only fit one way. The holes are slightly offset to center. Replace the screws, **DO NOT OVERTIGHTEN.**

LOW BATTERY INDICATOR

A weak battery can cause improper operation or inaccurate measurements. When "LOW BAT" indicator is illuminated replace the battery. Do not leave exhausted battery in the unit due to risk of leakage.

475-AV AIR VELOCITY KIT

Complete kits include a Series 475 manometer (standard ranges as shown on back of card), (2) No. A-303 static pressure tips, (2) nine ft. lengths of 3/16" I.D. rubber tubing, a Model 166-6-CF, 6" Pitot tube, No. A-397 step drill, No. A-532 air velocity slide chart and instructional bulletin H-11. All items are packed in a tough molded plastic carrying case with die cut foam liner.

- 475-000-FM
- 475-00-FM
- 475-0-FM
- 475-1-FM
- 475-2-FM
- 475-3-FM
- 475-4-FM
- 475-5-FM
- 475-6-FM
- 475-7-FM
- 475-8-FM

